




Counterweight must be present on the machine to activate PC-mode

# HOEFLON<sup>®</sup>

## C30e

## PC

